Philips
Water container

Original

Silent blue

CRP697

For water storage in your SENSEO® coffee machine

Go to the Specifications Tab to check your matching product

A water container should be cleaned regularly. Whenever that's the case, you'll be happy not to miss your coffee moment and to have an extra reservoir for your SENSEO® coffee machine. The tank contains 1.2 liter, for eight cups of coffee.

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS
sense and simplicity

Water container
Original Silent blue

CRP697/01

Specifications

Replaceable part
- Fits product types: HD7811/72

Highlights

Easy replacement
From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality and 1:1 exchange.

Issue date 2012-10-11

Version: 2.0.1

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com